

SwissBike

How to Fold

Step One: Remove the front wheel.

- Stand on chain side of the bike.
- Unlock the quick release lever on the front wheel.
- Remove the front wheel.

Step Two: Unlock the frame quick release.

- Stand on the chain side of the bike.
- Open the quick release lever on top of the tube - spin counter clockwise 5 to 6 complete rotations.

Step Three: Fold the bike.

- Press and hold down the quick release and fold the bike with the handle bars turned away from you so they fold into the rear wheel.
- For extra compactness, open the quick release below the saddle and lower the saddle all the way down.